

# WOODGRAFT

*Technologies, Inc.*

## 2 Piece Frame Slider Installation Instructions

### 50-0750 Kit

### 2009-16 BMW S1000RR, 2014-16 BMW S1000R

1) Remove your OEM motor mount bolts. The sliders use the most forward engine mounts shown below in the photographs.

#### FOR 2009-14 S1000RR & 2014-16 S1000R MODELS ONLY

*(2015 -16 S1000RR Models NO trimming is required proceed to step 3)*

2) With your bodywork in place, fit the bolt and aluminum base on the right side of the bike by hand so that you can trace a circle to mark where you need to trim for the slider. You will need to trim a two inch clear circle centered on the motor mount bolt on the right side, while the left does not require modification. A Dremel tool with a drum sanding bit works great. Note that on the '14-'16 S1000R BOTH side needs to be trimmed in order to fit the frame slider bases.

3) Attach the slider bases to the motorcycle using the 10mm bolts provided, threading them in place of your OEM motor mount bolt. Torque the bolt to OEM recommended specifications (consult service manual).

4) Slide the plastic slider over the top of the base and secure in place using the 8mm countersunk bolt provided. The bolt passes first through the non-threaded hole and then screws into the threaded hole on the far side of the base. The plastic is undersized on the far side of the slider to act as a locknut for the bolt.



**IMPORTANT:** The longer base goes on the left side, with the longer bolt