



Installation Instructions

Swingarm Spools and Slider Spools

IMPORTANT - USE BLUE LOCTITE on all bolts

- 1) Ensure that spool mounting locations are free of debris and ready for installation.
- 2) Follow the listing below to attain proper torque specifications.

Recommended Bolt Torque

- 6mm - 8 ft-lbs
- 8mm - 18 ft-lbs
- 10mm - 28 ft-lbs
- (use Blue Loctite)



WARNING: Improper installation and/or failure to comply with all warnings and instructions may cause a loss of control and serious injury or death. The motorcycle should be run and thoroughly inspected before use. DO NOT INSTALL OR USE THIS PRODUCT IF YOU ARE UNABLE TO DO SO IN COMPLIANCE WITH ALL INSTRUCTIONS AND WARNINGS. ALWAYS SEEK THE ASSISTANCE OF A TRAINED PROFESSIONAL TECHNICIAN.