



HINDLE PRODUCTS LTD.

140 North Port Road
Port Perry, Ontario
L9L 1B2, CANADA

Tel. (905) 985-6111 | Fax. (905) 985-7349



Installation Instructions - HINDLE EVOLUTION NOISE REDUCER

To install the HINDLE EVOLUTION NOISE REDUCER, proceed with the following directions:


Step 1: Observe “Start Position” of Evolution Noise Reducer in Image 1. Holding the noise reducer by the cylindrical material side, make sure that the cam start position matches that of Image 1.

Step 2: Insert noise reducer into tip of Evolution Muffler as shown in Image 2. Noise reducer should be 1/4” spaced away from end of Evolution muffler.


Step 3: Now that the noise reducer is inside the Evolution muffler, use needle nose pliers to hold the reducer in place while it will be tightened. Using a 6mm Allan Key, turn the bolt clockwise 180° to tighten. See Image 3.

Step 4: Check that noise reducer is securely tightened and that no parts are moveable. See Image 4 for final installation.


REAR VIEW



FRONT VIEW



SIDE VIEW INSTALLED



INSTALLED





WARNING

Exhaust system(s) and muffler(s) may be hot when engine is/has been running. Take preventative measures with the handling of any Hindle system or Hindle muffler. Allow the engine to cool before installing or removing the exhaust system and/or muffler. Severe burns, bodily injury and/or death may occur.



WARNING

Keep flammable materials away from exhaust at all times.



WARNING

Exhaust gas contains poisonous carbon monoxide that can rapidly accumulate in an enclosed or poorly ventilated area. If inhaled, it may cause serious injury or death. Start and run the motorcycle in a well-ventilated area.

12 MONTH LIMITED WARRANTY AND LIABILITY DISCLAIMER

Hindle Products Ltd. warrants this product free from defects in material or workmanship for a period of 12 months from the date of purchase, except as noted. The product warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product, improper installation, exposure to harsh weather and/or chemicals, lack of proper maintenance, or any other conditions that are beyond the control of Hindle Products Ltd. Hindle Products Ltd. shall not be responsible for any type of incidental, consequential, or special damages. All implied warranties, including but not limited to those warranties of fitness and merchantability, are limited in the total duration to 12 months from the original purchase date. Hindle will not warrant any product for fitment issues after the system has been ran on the motorcycle for any length of time. If the warranty occurs within 30 days from the date of purchase, please contact the dealer product was purchased from. Over 30 days from the date of purchase, please contact Hindle Products Ltd. direct at (905) 985-6111 before shipping the product. Customer must contact Hindle Products Ltd. prior to sending warranty product. Claims for lost shipment, damaged shipments, or other problems regarding freight must be made directly to the responsible carrier. To obtain warranty service on Hindle Exhaust System products, mail the product prepaid and a copy of your dated sales receipt (as proof of purchase), together with a note explaining the reason for repair to this item to: **Hindle Products Ltd., 140 North Port Road, Port Perry, Ontario, Canada, L9L 1B2.** Product being returned without notification prior to shipping will be overlooked. Upon receipt, Hindle Products Ltd. will repair or replace, as appropriate, your Hindle product and return it to you, post paid. Warranty is solely through Hindle Products Ltd. Service to our products by anyone other than Hindle Products Ltd. voids warranty. Hindle Products Ltd. disclaims any and all liability for consequential or incidental damages. Hindle Products Ltd. will not be held responsible for personal damage, bodily harm or any other legal matters. Hindle Exhaust Systems are for closed-course competition only.